

Osmo Oil Reapplication

THIS PRODUCT IS FOR USE WITH TAIT'S
ACCOYA® & SMOKED OAK TIMBERS ONLY

Osmo Oil is specifically formulated for high performance timbers. Osmo Oil is water repellent, UV resistant, and contains active ingredients which protect from mould, fungus and algae. Reapplication is easy and seamless, with no sanding or primer necessary.

1. Clean the timber surface with a mild soap solution, then rinse with plain water. Ensure the timber is completely dry before application and that you are working out of direct sunlight.
2. Thoroughly shake the supplied tin of Osmo Oil prior to opening.
3. With a clean rag, apply the oil thinly and evenly to the end grain first, then apply the topcoat to the timber slats, followed by wiping over the application (along the grain) with a rag. Remove any excess product immediately with a clean rag, paying particular attention to joints and grooves. Please note, wiping excess product after application is an important step to achieving a 'factory-like' finish.
4. If the surface/colour does not appear saturated, repeat step 3.
5. Allow 24 hours for the finish to harden thoroughly depending on weather and temperature.