

Teknos® Reapplication

THIS PRODUCT IS FOR USE WITH TAIT'S
ACCOYA® & SMOKED OAK TIMBERS ONLY

The Teknos® water-based coating system is specially formulated for use on high performance timbers and further assists in protecting timber from mould, fungus, green algae, trans-seasonal UV & moisture loss.

Please note:

- Tait DO NOT recommend you sand the timber.
- For best application results, we recommend working in a covered area out of direct sunlight, and during a cool time of day - under 20°C.

1. Prior to reapplication, clean the surface of the product with a mild soap solution and rinse with plain water. Leave the product to dry for 24 hours in the cool, covered location.

2. Shake the supplied tin of Teknos® topcoat (either opaque or translucent), thoroughly prior to opening.

3. The reapplication will work best with 2 rags/cloths - using one in each hand one to apply the product, the other to immediately remove the excess product. We recommend working the product on to the timber quickly.

4. Apply the end grain first, then apply a generous amount of the topcoat to the timber slats, wiping along the grain. Wipe off any excess product immediately with a clean rag/cloth (even in cooler weather the product will dry quickly). Take particular care to remove excess from joints and grooves. Wiping off the excess product is a very important step to achieving a good 'factory like' finish.

5. If the surface/colour does not appear saturated, repeat steps 3 and 4.

6. It takes 24 hours for the finish to harden thoroughly, depending on weather conditions and outdoor temperature. The timber must not be exposed to water during this period.